

Agricultural Best Management Practices (BMPs) for Water Quality Protection



Condition before improvements



Condition before improvements



**Percolation Test** 



1) Settling Tank & 2) Flout Tank




Gravity flow from first tank to second tank



Zabel filter in first tank



Flout in second tank



Flout in second tank



Boring under road



Pulling pipe under road



Distribution box



Installing infiltrator chambers in trenches



Backfilling infiltrator chambers

#### Milkhouse Wastewater System (2 tanks with gravity flow to infiltrator chambers)

#### **Material List:**

- 1 1000 gallon septic tanks (grease trap) with baffles
  - coated
  - with 2 risers per tank
- 1 Zabel Filter
  - Model A300 8 x 18 -VC
- 1 1000 gallon utility tank with bottom outlet for Flout
  - with 1 riser
- 1 Flout
- dose 800 gallons per flush
- 550 feet 4" Sch 40 PVC pipe
  - plus assorted pipe fittings
- 1 Distribution box
  - 6 hole
- 108 feet Infiltrator Chambers
  - (27) Quick 4 Standard Chambers
  - with 6 end caps

Note: All quantities are estimated.

#### Milkhouse Wastewater:

#### Typical material list



## Waste Storage:

Daily spreading in winter



Picking a suitable site for a waste storage structure



Digging the core trench for earthen berm



Building the earthen berm



Compacting the earthen berm



Finishing the earthen berm



It holds water!



Installing the liner



Concrete ramp over liner



Fence and gates in place



Digging test pits



Checking floor elevation



Finished base for floor



Concrete floor with waterstop and rebar



Wall form with double row of rebar



Pouring concrete for wall



Completed structure with loading pad and fence/gate



Waste transfer line with clean out



Transfer line with duckbill valve



Manure cross channel in barn



Manure reception pit in barn



Concrete Waste Storage:

Manure pump for transfer from barn to storage



Rebar for footer



Installing starter strip for wall panels



Installing jacks for raising wall panels



Installing wall panels



Flapper valve on transfer line



Loading pad and pump



Barnyard - before



Barnyard - before



Barnyard – after (gutter on roof)



Barnyard – after (concrete pad)



Barnyard – after (Fence & wood curbs)



Screen box to collect solids



Transfer pipe to VTA



Before



Dripline trench ready for pipe and #2 stone



Dripline trench with 4" PVC pipe



Completed dripline to convey roofwater away from barn



#### Diversion:

Grassed waterway to divert surface water away from barn



#### Diversion:

Stone-lined waterway to divert surface water away from barn





Before









Bunk silo – slopes to one point



Detail showing separation of concentrated low flows from bunk runoff



Pipe for low flows from bunk to holding tank



Pipe for diluted high flows from bunk to VTA